



OM-266G

February 1993

Eff. w/Serial Number KB022118

Processes



TIG (GTAW) Welding



Stick (SMAW) Welding



Air Carbon Arc (CAC-A)
Cutting and Gouging




MIG (GMAW) Welding
Flux Cored (FCAW) Welding

Description



Arc Welding Power Source For Use
With A MOG System

GPS-500, GPS-750



OWNER'S MANUAL



Visit our website at
www.MillerWelds.com

From Miller to You

Thank you and congratulations on choosing Miller. Now you can get the job done and get it done right. We know you don't have time to do it any other way.

That's why when Niels Miller first started building arc welders in 1929, he made sure his products offered long-lasting value and superior quality. Like you, his customers couldn't afford anything less. Miller products had to be more than the best they could be. They had to be the best you could buy.

Today, the people that build and sell Miller products continue the tradition. They're just as committed to providing equipment and service that meets the high standards of quality and value established in 1929.

This Owner's Manual is designed to help you get the most out of your Miller products. Please take time to read the Safety precautions. They will help you protect yourself against potential hazards on the worksite. We've



Miller is the first welding equipment manufacturer in the U.S.A. to be registered to the ISO 9001 Quality System Standard.

made installation and operation quick and easy. With Miller you can count on years of reliable service with proper maintenance. And if for some reason the unit needs repair, there's a Troubleshooting section that will help you figure out what the problem is. The parts list will then help you to decide which exact part you may need to fix the problem. Warranty and service information for your particular model are also provided.

Miller Electric manufactures a full line of welders and welding related equipment. For information on other quality Miller products, contact your local Miller distributor to receive the latest full line catalog or individual catalog sheets. **To locate your nearest distributor or service agency call 1-800-4-A-Miller, or visit us at www.MillerWelds.com on the web.**



Working as hard as you do – every power source from Miller is backed by the most hassle-free warranty in the business.

Miller offers a Technical Manual which provides more detailed service and parts information for your unit. To obtain a Technical Manual, contact your local distributor. Your distributor can also supply you with Welding Process Manuals such as SMAW, GTAW, GMAW, and GMAW-P.



TABLE OF CONTENTS

The following terms are used interchangeably throughout this manual:
TIG = GTAW
Stick = SMAW

| | |
|---|-----------|
| SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING | 1 |
| 1-1. Symbol Usage | 1 |
| 1-2. Arc Welding Hazards | 1 |
| 1-3. Additional Symbols for Installation, Operation, and Maintenance | 3 |
| 1-4. Principal Safety Standards | 3 |
| 1-5. EMF Information | 4 |
| SECTION 1 – CONSIGNES DE SECURITE – LIRE AVANT UTILISATION | 5 |
| 1-1. Signification des symboles | 5 |
| 1-2. Dangers relatifs au soudage à l'arc | 5 |
| 1-3. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance | 7 |
| 1-4. Principales normes de sécurité | 8 |
| 1-5. Information sur les champs électromagnétiques | 8 |
| SECTION 2 – SPECIFICATIONS | 9 |
| 2-1. Specifications | 9 |
| 2-2. Volt-Ampere Curve | 9 |
| 2-3. Duty Cycle | 10 |
| SECTION 3 – INSTALLATION | 10 |
| 3-1. Typical Connections | 10 |
| 3-2. Selecting A Location And Moving Welding Power Source | 11 |
| 3-3. Overall Dimensions And Base Mounting Hole Layout | 11 |
| 3-4. Selecting And Preparing Weld Output Cables | 12 |
| 3-5. Weld Cable Size* | 12 |
| 3-6. Connecting To Weld Output Terminals | 13 |
| 3-7. Positioning Jumper Links | 14 |
| 3-8. Connecting Input Power | 15 |
| 3-9. Electrical Service Requirements For 500 Ampere Models* | 15 |
| 3-10. Electrical Service Requirements For 750 Ampere Models* | 16 |
| SECTION 4 – OPERATION | 16 |
| 4-1. Controls | 16 |
| 4-2. Safety Equipment | 16 |
| 4-3. Work Clamp | 17 |
| 4-4. Ammeter And Voltmeter | 17 |
| 4-5. Power Control Push Buttons And Pilot Light | 17 |
| 4-6. Sequence Of Shielded Metal Arc Welding (SMAW) | 17 |
| 4-7. Sequence Of Gas Metal Arc Welding (GMAW) | 18 |
| 4-8. Sequence Of Flux Cored Arc Welding (FCAW) | 18 |
| 4-9. Sequence Of Gas Tungsten Arc Welding (GTAW) | 18 |
| 4-10. Sequence Of Air Carbon Arc Cutting And Gouging (CAC-A) | 18 |
| SECTION 5 – MAINTENANCE & TROUBLESHOOTING | 19 |
| 5-1. Routine Maintenance | 19 |
| 5-2. Overload Protection | 19 |
| 5-3. Troubleshooting | 21 |
| SECTION 6 – ELECTRICAL DIAGRAMS | 23 |
| SECTION 7 – PARTS LIST | 24 |
| OPTIONS AND ACCESSORIES | |
| WARRANTY | |

SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING

som_nd_5/97

1-1. Symbol Usage



Means Warning! Watch Out! There are possible hazards with this procedure! The possible hazards are shown in the adjoining symbols.

▲ Marks a special safety message.

☞ Means "Note"; not safety related.



This group of symbols means Warning! Watch Out! possible ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards.

1-2. Arc Welding Hazards

▲ The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-4. Read and follow all Safety Standards.

▲ Only qualified persons should install, operate, maintain, and repair this unit.

▲ During operation, keep everybody, especially children, away.



ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also


live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.
- Always verify the supply ground – check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first – double-check connections.
- Frequently inspect input power cord for damage or bare wiring – replace cord immediately if damaged – bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or poorly spliced cables.
- Do not drape cables over your body.

- If earth grounding of the workpiece is required, ground it directly with a separate cable – do not use work clamp or work cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal.

SIGNIFICANT DC VOLTAGE exists after removal of input power on inverters.

- Turn Off inverter, disconnect input power, and discharge input capacitors according to instructions in Maintenance Section before touching any parts.



FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use exhaust at the arc to remove welding fumes and gases.
- If ventilation is poor, use an approved air-supplied respirator.
- Read the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watch-person nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and if necessary, while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.


- Wear a welding helmet fitted with a proper shade of filter to protect your face and eyes when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash and glare; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (leather and wool) and foot protection.



WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Protect yourself and others from flying sparks and hot metal.
- Do not weld where flying sparks can strike flammable material.
- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared according to AWS F4.1 (see Safety Standards).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock and fire hazards.
- Do not use welder to thaw frozen pipes.
- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.



FLYING METAL can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.




BUILDUP OF GAS can injure or kill.

- Shut off shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.




HOT PARTS can cause severe burns.

- Do not touch hot parts bare handed.
- Allow cooling period before working on gun or torch.



MAGNETIC FIELDS can affect pacemakers.


- Pacemaker wearers keep away.
- Wearers should consult their doctor before going near arc welding, gouging, or spot welding operations.



NOISE can damage hearing.

Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



CYLINDERS can explode if damaged.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder – explosion will result.
- Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Read and follow instructions on compressed gas cylinders, associated equipment, and CGA publication P-1 listed in Safety Standards.

1-3. Additional Symbols For Installation, Operation, And Maintenance




FIRE OR EXPLOSION hazard.

- Do not install or place unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.




FALLING UNIT can cause injury.

- Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories.
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.



OVERUSE can cause OVERHEATING

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.



STATIC (ESD) can damage PC boards.

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.



MOVING PARTS can cause injury.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.




WELDING WIRE can cause injury.

- Do not press gun trigger until instructed to do so.
- Do not point gun toward any part of the body, other people, or any metal when threading welding wire.




MOVING PARTS can cause injury.

- Keep away from moving parts such as fans.
- Keep all doors, panels, covers, and guards closed and securely in place.



H.F. RADIATION can cause interference.

- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.



ARC WELDING can cause interference.

- Electromagnetic energy can interfere with sensitive electronic equipment such as computers and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.

1-4. Principal Safety Standards

Safety in Welding and Cutting, ANSI Standard Z49.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami FL 33126

Safety and Health Standards, OSHA 29 CFR 1910, from Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402.

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers That Have Held Hazardous Substances, American Welding Society Standard AWS F4.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202.

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3.

Safe Practices For Occupation And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 1430 Broadway, New York, NY 10018.

Cutting And Welding Processes, NFPA Standard 51B, from National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

1-5. EMF Information

Considerations About Welding And The Effects Of Low Frequency Electric And Magnetic Fields

Welding current, as it flows through welding cables, will cause electromagnetic fields. There has been and still is some concern about such fields. However, after examining more than 500 studies spanning 17 years of research, a special blue ribbon committee of the National Research Council concluded that: "The body of evidence, in the committee's judgment, has not demonstrated that exposure to power-frequency electric and magnetic fields is a human-health hazard." However, studies are still going forth and evidence continues to be examined. Until the final conclusions of the research are reached, you may wish to minimize your exposure to electromagnetic fields when welding or cutting.

To reduce magnetic fields in the workplace, use the following procedures:

1. Keep cables close together by twisting or taping them.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.
4. Keep welding power source and cables as far away from operator as practical.
5. Connect work clamp to workpiece as close to the weld as possible.

About Pacemakers:

Pacemaker wearers consult your doctor first. If cleared by your doctor, then following the above procedures is recommended.

SECTION 1 – CONSIGNES DE SECURITE – LIRE AVANT UTILISATION

som _nd_fre 5/97

1-1. Signification des symboles



Signifie Mise en garde ! Soyez vigilant ! Cette procédure présente des risques de danger ! Ceux-ci sont identifiés par des symboles adjacents aux directives.

▲ Identifie un message de sécurité particulier.

 Signifie NOTA ; n'est pas relatif à la sécurité.



Ce groupe de symboles signifie Mise en garde ! Soyez vigilant ! Il y a des risques de danger reliés aux CHOCS ÉLECTRIQUES, aux PIÈCES EN MOUVEMENT et aux PIÈCES CHAUDES. Reportez-vous aux symboles et aux directives ci-dessous afin de connaître les mesures à prendre pour éviter tout danger.

1-2. Dangers relatifs au soudage à l'arc

▲ Les symboles présentés ci-après sont utilisés tout au long du présent manuel pour attirer votre attention et identifier les risques de danger. Lorsque vous voyez un symbole, soyez vigilant et suivez les directives mentionnées afin d'éviter tout danger. Les consignes de sécurité présentées ci-après ne font que résumer l'information contenue dans les normes de sécurité énumérées à la section 1-4. Veuillez lire et respecter toutes ces normes de sécurité.

▲ L'installation, l'utilisation, l'entretien et les réparations ne doivent être confiés qu'à des personnes qualifiées.

▲ Au cours de l'utilisation, tenir toute personne à l'écart et plus particulièrement les enfants.



UN CHOC ÉLECTRIQUE peut tuer.


Un simple contact avec des pièces électriques peut provoquer une électrocution ou des blessures graves. L'électrode et le circuit de soudage sont sous tension dès que l'appareil est sur ON. Le circuit d'entrée et les circuits internes de l'appareil sont également sous tension à ce moment-là. En soudage semi-automatique ou automatique, le fil, le dévidoir, le logement des galets d'entraînement et les pièces métalliques en contact avec le fil de soudage sont sous tension. Des matériels mal installés ou mal mis à la terre présentent un danger.

- Ne jamais toucher les pièces électriques sous tension.
- Porter des gants et des vêtements de protection secs ne comportant pas de trous.
- S'isoler de la pièce et de la terre au moyen de tapis ou d'autres moyens isolants suffisamment grands pour empêcher le contact physique éventuel avec la pièce ou la terre.
- Ne pas se servir de source électrique à courant électrique dans les zones humides, dans les endroits confinés ou là où on risque de tomber.
- Se servir d'une source électrique à courant électrique UNIQUEMENT si le procédé de soudage le demande.
- Si l'utilisation d'une source électrique à courant électrique s'avère nécessaire, se servir de la fonction de télécommande si l'appareil en est équipé.
- Couper l'alimentation ou arrêter le moteur avant de procéder à l'installation, à la réparation ou à l'entretien de l'appareil. Déverrouiller l'alimentation selon la norme OSHA 29 CFR 1910.147 (voir normes de sécurité).
- Installer et mettre à la terre correctement cet appareil conformément à son manuel d'utilisation et aux codes nationaux, provinciaux et municipaux.
- Toujours vérifier la terre du cordon d'alimentation – Vérifier et s'assurer que le fil de terre du cordon d'alimentation est bien raccordé à la borne de terre du sectionneur ou que la fiche du cordon est raccordée à une prise correctement mise à la terre.
- En effectuant les raccordements d'entrée fixer d'abord le conducteur de mise à la terre approprié et contre-vérifier les connexions.
- Vérifier fréquemment le cordon d'alimentation pour voir s'il n'est pas endommagé ou dénudé – remplacer le cordon immédiatement s'il est endommagé – un câble dénudé peut provoquer une électrocution.
- Mettre l'appareil hors tension quand on ne l'utilise pas.
- Ne pas utiliser des câbles usés, endommagés, de grosseur insuffisante ou mal épluchés.
- Ne pas enrouler les câbles autour du corps.
- Si la pièce soudée doit être mise à la terre, le faire directement avec un câble distinct – ne pas utiliser le connecteur de pièce ou le câble de retour.

- Ne pas toucher l'électrode quand on est en contact avec la pièce, la terre ou une électrode provenant d'une autre machine.
- N'utiliser qu'un matériel en bon état. Réparer ou remplacer sur-le-champ les pièces endommagées. Entretien l'appareil conformément à ce manuel.
- Porter un harnais de sécurité quand on travaille en hauteur.
- Maintenir solidement en place tous les panneaux et capots.
- Fixer le câble de retour de façon à obtenir un bon contact métal-métal avec la pièce à souder ou la table de travail, le plus près possible de la soudure.
- Isoler la pince de masse quand pas mis à la pièce pour éviter le contact avec tout objet métallique.

Il y a DU COURANT CONTINU IMPORTANT dans les convertisseurs après la suppression de l'alimentation électrique.

- Arrêter les convertisseurs, débrancher le courant électrique, et décharger les condensateurs d'alimentation selon les instructions indiquées dans la partie entretien avant de toucher les pièces.



LES FUMÉES ET LES GAZ peuvent être dangereux.

Le soudage génère des fumées et des gaz. Leur inhalation peut être dangereux pour votre santé.

- Eloigner votre tête des fumées. Ne pas respirer les fumées.
- A l'intérieur, ventiler la zone et/ou utiliser un échappement au niveau de l'arc pour l'évacuation des fumées et des gaz de soudage.
- Si la ventilation est insuffisante, utiliser un respirateur à alimentation d'air homologué.
- Lire les spécifications de sécurité des matériaux (MSDSs) et les instructions du fabricant concernant les métaux, les consommables, les revêtements, les nettoyants et les dégraissants.
- Travailler dans un espace fermé seulement s'il est bien ventilé ou en portant un respirateur à alimentation d'air. Demander toujours à un surveillant dûment formé de se tenir à proximité. Des fumées et des gaz de soudage peuvent déplacer l'air et abaisser le niveau d'oxygène provoquant des blessures ou des accidents mortels. S'assurer que l'air de respiration ne présente aucun danger.
- Ne pas souder dans des endroits situés à proximité d'opérations de dégraissage, de nettoyage ou de pulvérisation. La chaleur et les rayons de l'arc peuvent réagir en présence de vapeurs et former des gaz hautement toxiques et irritants.
- Ne pas souder des métaux munis d'un revêtement, tels que l'acier galvanisé, plaqué en plomb ou au cadmium à moins que le revêtement n'ait été enlevé dans la zone de soudure, que l'endroit soit bien ventilé, et si nécessaire, en portant un respirateur à alimentation d'air. Les revêtements et tous les métaux renfermant ces éléments peuvent dégager des fumées toxiques en cas de soudage.



LES RAYONS DE L'ARC peuvent provoquer des brûlures dans les yeux et sur la peau.

Le rayonnement de l'arc du procédé de soudage génère des rayons visibles et invisibles intenses (ultraviolets et infrarouges) susceptibles de provoquer des brûlures dans les yeux et sur la peau. Des étincelles sont projetées pendant le soudage.


- Porter un casque de soudage muni d'un écran de filtre approprié pour protéger votre visage et vos yeux pendant le soudage ou pour regarder (voir ANSI Z49.1 et Z87.1 énuméré dans les normes de sécurité).
- Porter des protections approuvés pour les oreilles si le niveau sonore est trop élevé.
- Utiliser des écrans ou des barrières pour protéger des tiers de l'éclair et de l'éblouissement; demander aux autres personnes de ne pas regarder l'arc.
- Porter des vêtements de protection constitué dans une matière durable, résistant au feu (cuir ou laine) et une protection des pieds.



LE SOUDAGE peut provoquer un incendie ou une explosion.

Le soudage effectué sur des conteneurs fermés tels que des réservoirs, tambours ou des conduites peut provoquer leur éclatement. Des étincelles peuvent être projetées de l'arc de soudure. La projection d'étincelles, des pièces chaudes et des équipements chauds peut provoquer des incendies et des brûlures. Le contact accidentel de l'électrode avec des objets métalliques peut provoquer des étincelles, une explosion, un surchauffement ou un incendie. Avant de commencer le soudage, vérifier et s'assurer que l'endroit ne présente pas de danger.

- Se protéger et d'autres personnes de la projection d'étincelles et de métal chaud.
- Ne pas souder dans un endroit où des étincelles peuvent tomber sur des substances inflammables.
- Déplacer toutes les substances inflammables à une distance de 10,7 m de l'arc de soudage. En cas d'impossibilité les recouvrir soigneusement avec des protections homologués.
- Des étincelles et des matériaux chauds du soudage peuvent facilement passer dans d'autres zones en traversant de petites fissures et des ouvertures.
- Surveiller tout déclenchement d'incendie et tenir un extincteur à proximité.
- Le soudage effectué sur un plafond, plancher, paroi ou séparation peut déclencher un incendie de l'autre côté.
- Ne pas effectuer le soudage sur des conteneurs fermés tels que des réservoirs, tambours, ou conduites, à moins qu'ils n'aient été préparés correctement conformément à AWS F4.1 (voir les normes de sécurité).
- Brancher le câble sur la pièce la plus près possible de la zone de soudage pour éviter le transport du courant sur une longue distance par des chemins inconnus éventuels en provoquant des risques d'électrocution et d'incendie.
- Ne pas utiliser le poste de soudage pour dégelier des conduites gelées.
- En cas de non utilisation, enlever la baguette d'électrode du porte-électrode ou couper le fil à la pointe de contact.
- Porter des vêtements de protection dépourvus d'huile tels que des gants en cuir, une chemise en matériau lourd, des pantalons sans revers, des chaussures hautes et un couvre chef.
- Avant de souder, retirer toute substance combustible de vos poches telles qu'un allumeur au butane ou des allumettes.



DES PARTICULES VOLANTES peuvent blesser les yeux.

- Le soudage, l'écaillage, le passage de la pièce à la brosse en fil de fer, et le meulage génèrent des étincelles et des particules métalliques volantes. Pendant la période de refroidissement des soudures, elles risquent de projeter du laitier.
- Porter des lunettes de sécurité avec écrans latéraux ou un écran facial.



LES ACCUMULATIONS DE GAZ risquent de provoquer des blessures ou même la mort.

- Fermer l'alimentation du gaz protecteur en cas de non utilisation.
- Veiller toujours à bien aérer les espaces confinés ou se servir d'un respirateur d'adduction d'air homologué.




DES PIÈCES CHAUDES peuvent provoquer des brûlures graves.

- Ne pas toucher des parties chaudes à mains nues
- Prévoir une période de refroidissement avant d'utiliser le pistolet ou la torche.



LES CHAMPS MAGNÉTIQUES peuvent affecter les stimulateurs cardiaques.


- Porteurs de stimulateur cardiaque, restez à distance.
- Les porteurs d'un stimulateur cardiaque doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de gougeage ou de soudage par points.



LE BRUIT peut affecter l'ouïe.

Le bruit des processus et des équipements peut affecter l'ouïe.

- Porter des protections approuvés pour les oreilles si le niveau sonore est trop élevé.



Si des BOUTEILLES sont endommagées, elles pourront exploser.

Des bouteilles de gaz protecteur contiennent du gaz sous haute pression. Si une bouteille est endommagée, elle peut exploser. Du fait que les bouteilles de gaz font normalement partie du procédé de soudage, les manipuler avec précaution.

- Protéger les bouteilles de gaz comprimé d'une chaleur excessive, des chocs mécaniques, du laitier, des flammes ouvertes, des étincelles et des arcs.
- Placer les bouteilles debout en les fixant dans un support stationnaire ou dans un porte-bouteilles pour les empêcher de tomber ou de se renverser.
- Tenir les bouteilles éloignées des circuits de soudage ou autres circuits électriques.
- Ne jamais placer une torche de soudage sur une bouteille à gaz.
- Une électrode de soudage ne doit jamais entrer en contact avec une bouteille.
- Ne jamais souder une bouteille pressurisée – risque d'explosion.
- Utiliser seulement des bouteilles de gaz protecteur, régulateurs, tuyaux et raccords convenables pour cette application spécifique; les maintenir ainsi que les éléments associés en bon état.
- Ne pas tenir la tête en face de la sortie en ouvrant la soupape de la bouteille.
- Maintenir le chapeau de protection sur la soupape, sauf en cas d'utilisation ou de branchement de la bouteille.
- Lire et suivre les instructions concernant les bouteilles de gaz comprimé, les équipements associés et les publications P-1 CGA énumérées dans les normes de sécurité.

1-3. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance




Risque D'INCENDIE OU D'EXPLOSION.

- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Ne pas installer l'appareil à proximité de produits inflammables
- Ne pas surcharger l'installation électrique – s'assurer que l'alimentation est correctement dimensionnée et protégée avant de mettre l'appareil en service.




LA CHUTE DE L'APPAREIL peut blesser.

- Utiliser l'anneau de levage uniquement pour soulever l'appareil, NON PAS les chariot, les bouteilles de gaz ou tout autre accessoire.
- Utiliser un engin d'une capacité appropriée pour soulever l'appareil.
- En utilisant des fourches de levage pour déplacer l'unité, s'assurer que les fourches sont suffisamment longues pour dépasser du côté opposé de l'appareil.




L'EMPLOI EXCESSIF peut SURCHAUFFER L'ÉQUIPEMENT.

- Prévoir une période de refroidissement, respecter le cycle opératoire nominal.
- Réduire le courant ou le cycle opératoire avant de recommencer le soudage.
- Ne pas obstruer les passages d'air du poste.



LES CHARGES ÉLECTROSTATIQUES peuvent endommager les circuits imprimés.

- Établir la connexion avec la barrette de terre avant de manipuler des cartes ou des pièces.
- Utiliser des pochettes et des boîtes antistatiques pour stocker, déplacer ou expédier des cartes de circuits imprimés.



DES ORGANES MOBILES peuvent provoquer des blessures.

- Ne pas s'approcher des organes mobiles.
- Ne pas s'approcher des points de coincement tels que des rouleaux de commande.




LES FILS DE SOUDAGE peuvent provoquer des blessures.

- Ne pas appuyer sur la gachette avant d'en avoir reçu l'instruction.
- Ne pas diriger le pistolet vers soi, d'autres personnes ou toute pièce mécanique en engageant le fil de soudage.




DES ORGANES MOBILES peuvent provoquer des blessures.

- Rester à l'écart des organes mobiles comme le ventilateur.
- Maintenir fermés et fixement en place les portes, panneaux, recouvrements et dispositifs de protection.



LE RAYONNEMENT HAUTE FRÉQUENCE (H.F.) risque de provoquer des interférences.

- Le rayonnement haute fréquence peut provoquer des interférences avec les équipements de radio-navigation et de communication, les services de sécurité et les ordinateurs.
- Demander seulement à des personnes qualifiées familiarisées avec des équipements électroniques de faire fonctionner l'installation.
- L'utilisateur est tenu de faire corriger rapidement par un électricien qualifié les interférences résultant de l'installation.
- Si le FCC signale des interférences, arrêter immédiatement l'appareil.
- Effectuer régulièrement le contrôle et l'entretien de l'installation.
- Maintenir soigneusement fermés les portes et les panneaux des sources de haute fréquence, maintenir les éclateurs à une distance correcte et utiliser une terre et un blindage pour réduire les interférences éventuelles.



LE SOUDAGE À L'ARC risque de provoquer des interférences.

- L'énergie électromagnétique risque de provoquer des interférences pour l'équipement électronique sensible tel que les ordinateurs et l'équipement commandé par ordinateur tel que les robots.
- Veiller à ce que tout l'équipement de la zone de soudage soit compatible électromagnétiquement.
- Pour réduire la possibilité d'interférence, maintenir les câbles de soudage aussi courts que possible, les grouper, et les poser aussi bas que possible (ex. par terre).
- Veiller à souder à une distance de 100 mètres de tout équipement électronique sensible.
- Veiller à ce que ce poste de soudage soit posé et mis à la terre conformément à ce mode d'emploi.
- En cas d'interférences après avoir pris les mesures précédentes, il incombe à l'utilisateur de prendre des mesures supplémentaires telles que le déplacement du poste, l'utilisation de câbles blindés, l'utilisation de filtres de ligne ou la pose de protecteurs dans la zone de travail.



LES CHAMPS MAGNÉTIQUES peuvent affecter les stimulateurs cardiaques.

- Porteurs de stimulateur cardiaque, restez à distance.
- Les porteurs d'un stimulateur cardiaque doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de gougeage ou de soudage par points.

1-4. Principales normes de sécurité

Safety in Welding and Cutting, norme ANSI Z49.1, de l'American Welding Society, 550 N.W. Lejeune Rd, Miami FL 33126

Safety and Health Standards, OSHA 29 CFR 1910, du Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402.

Recommended Safe Practice for the Preparation for Welding and Cutting of Containers That Have Held Hazardous Substances, norme AWS F4.1, de l'American Welding Society, 550 N.W. Lejeune Rd, Miami FL 33126

National Electrical Code, NFPA Standard 70, de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, de la Compressed Gas Association, 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202.

Règles de sécurité en soudage, coupage et procédés connexes, norme CSA W117.2, de l'Association canadienne de normalisation, vente de normes, 178 Rexdale Boulevard, Rexdale (Ontario) Canada M9W 1R3.

Safe Practices For Occupation And Educational Eye And Face Protection, norme ANSI Z87.1, de l'American National Standards Institute, 1430 Broadway, New York, NY 10018.

Cutting and Welding Processes, norme NFPA 51B, de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

1-5. Information sur les champs électromagnétiques

Données sur le soudage électrique et sur les effets, pour l'organisme, des champs magnétiques basse fréquence

Le courant de soudage, pendant son passage dans les câbles de soudage, causera des champs électromagnétiques. Il y a eu et il y a encore un certain souci à propos de tels champs. Cependant, après avoir examiné plus de 500 études qui ont été faites pendant une période de recherche de 17 ans, un comité spécial ruban bleu du National Research Council a conclu: "L'accumulation de preuves, suivant le jugement du comité, n'a pas démontré que l'exposition aux champs magnétiques et champs électriques à haute fréquence représente un risque à la santé humaine". Toutefois, des études sont toujours en cours et les preuves continuent à être examinées. En attendant que les conclusions finales de la recherche soient établies, il vous serait souhaitable de réduire votre exposition aux champs électromagnétiques pendant le soudage ou le coupage.

Afin de réduire les champs électromagnétiques dans l'environnement de travail, respecter les consignes suivantes :

- 1 Garder les câbles ensemble en les torsadant ou en les attachant avec du ruban adhésif.
- 2 Mettre tous les câbles du côté opposé de l'opérateur.
- 3 Ne pas courber pas et ne pas entourer pas les câbles autour de votre corps.
- 4 Garder le poste de soudage et les câbles le plus loin possible de vous.
- 5 Relier la pince de masse le plus près possible de la zone de soudure.

Consignes relatives aux stimulateurs cardiaques :


Les personnes qui portent un stimulateur cardiaque doivent avant tout consulter leur docteur. Si vous êtes déclaré apte par votre docteur, il est alors recommandé de respecter les consignes ci-dessus.

SECTION 2 – SPECIFICATIONS


2-1. Specifications

| Specification | Description | |
|-------------------------------|--|---|
| Type Of Output | Direct Current/Constant Voltage (DC/CV) | |
| Welding Processes | Shielded Metal Arc (SMAW), Gas Metal Arc (GMAW), Flux Core Arc (FCAW), Gas Tungsten Arc Welding (GTAW), Air Carbon Arc (CAC-A) Gouging, Stress Relieving, Resistance Heating | |
| Overall Dimensions | See Section 3-3 | |
| Options | See Rear Cover | |
| | 500 Amp | 750 Amp |
| Rated Weld Output | 500 Amperes, 76 Volts DC At 100% Duty Cycle | 750 Amperes, 76 Volts DC At 100% Duty Cycle |
| Type Of Input Power | Three-Phase; 230, 460, Or 575 Volts AC; 60 Hz | Three-Phase; 230, 460, Or 575 Volts AC; 60 Hz |
| Input Amperes At Rated Output | 106 A At 230 V, 53 A At 460 V, 43 A At 575 V | 164 A At 230 V, 82 A At 460 V, 66 A At 575 V |
| KVA/KW Used At Rated Output | 42.8 kVA/41.7 kW | 65.3 kVA/61.5 kW |
| Max. Open-Circuit Voltage | 85 Volts DC | 85 Volts DC |
| Weight | Net: 480 lbs (218 kg); Ship 500 lbs (227 kg) | Net: 660 lbs (299 kg); Ship 680 lbs (308 kg) |

2-2. Volt-Ampere Curve



2-3. Duty Cycle



Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.


This unit is rated at 100% duty cycle allowing continuous operation at rated load.

▲ Exceeding duty cycle can damage unit and void warranty.


sb1.1 2/92 – Ref. SB-079 809-A



SECTION 3 – INSTALLATION

3-1. Typical Connections



3-2. Selecting A Location And Moving Welding Power Source





- 1 18 in (460 mm) Open Space
On Front And Rear For Good
Airflow
- 2 Lifting Eye
Use lifting eye to move unit.
- 3 Lifting Forks
If using lifting forks, extend forks out
opposite end of unit.
- 4 Rating Label
Locate unit near correct input pow-
er supply.

ST-158 380-A

3-3. Overall Dimensions And Base Mounting Hole Layout

| | Inches | Millimeters |
|----|--------|-------------|
| A | 34 | 864 |
| B | 22-1/4 | 565 |
| C* | 32 | 813 |
| D+ | 1-3/4 | 44 |
| E♦ | 28-3/4 | 730 |
| F | 1-1/8 | 29 |
| G | 20 | 508 |
| H | 7/16 | 11 |

*40 in (1016 mm) On 750 Amp Models
 +1-1/2 in (38 mm) On 750 Amp Models
 ♦ 37 in (940 mm) On 750 Amp Models

ST-158 377-A

3-4. Selecting And Preparing Weld Output Cables

1 Weld Output Cable

Determine total cable length in weld circuit and maximum welding amperes. Use Section 3-5 to select proper cable size.

Use shortest cables possible.

Do not use damaged cables.

2 Terminal Lug

Use lugs of proper amperage capacity and hole size for connecting to MOG terminal, and weld output terminals and work connection.

Tools Needed:

For Example,
Total Cable
Length In Weld
Circuit = 20 ft (6 m)

sb6.1* 8/92 – Ref. S-0653

3-5. Weld Cable Size*

| Welding Amperes | Total Cable (Copper) Length In Weld Circuit Not Exceeding | | | | | | | |
|--------------------|---|----------------------------|-------------------------|------------------|------------------|------------------|-------------------|-------------------|
| | 100 ft (30 m) Or Less | | 150 ft (45 m) | 200 ft (60 m) | 250 ft (70 m) | 300 ft (90 m) | 350 ft (105 m) | 400 ft (120 m) |
| | 10 To 60% Duty Cycle | 60 Thru 100% Duty Cycle | 10 Thru 100% Duty Cycle | | | | | |
| 100 | 4 | 4 | 4 | 3 | 2 | 1 | 1/0 | 1/0 |
| 150 | 3 | 3 | 2 | 1 | 1/0 | 2/0 | 3/0 | 3/0 |
| 200 | 3 | 2 | 1 | 1/0 | 2/0 | 3/0 | 4/0 | 4/0 |
| 250 | 2 | 1 | 1/0 | 2/0 | 3/0 | 4/0 | 2-2/0 | 2-2/0 |
| 300 | 1 | 1/0 | 2/0 | 3/0 | 4/0 | 2-2/0 | 2-3/0 | 2-3/0 |
| 350 | 1/0 | 2/0 | 3/0 | 4/0 | 2-2/0 | 2-3/0 | 2-3/0 | 2-4/0 |
| 400 | 1/0 | 2/0 | 3/0 | 4/0 | 2-2/0 | 2-3/0 | 2-4/0 | 2-4/0 |
| 500 | 2/0 | 3/0 | 4/0 | 2-2/0 | 2-3/0 | 2-4/0 | 3-3/0 | 3-3/0 |
| 600 | 3/0 | 4/0 | 2-2/0 | 2-3/0 | 2-4/0 | 3-3/0 | 3-4/0 | 3-4/0 |
| 700 | 4/0 | 2-2/0 | 2-3/0 | 2-4/0 | 3-3/0 | 3-4/0 | 3-4/0 | 4-4/0 |
| 800 | 4/0 | 2-2/0 | 2-3/0 | 2-4/0 | 3-4/0 | 3-4/0 | 4-4/0 | 4-4/0 |
| 900 | 2-2/0 | 2-3/0 | 2-4/0 | 3-3/0 | 3-4/0 | 4-4/0 | 4-4/0 | |
| 1000 | 2-2/0 | 2-3/0 | 2-4/0 | 3-3/0 | 4-3/0 | 4-4/0 | | |
| 1250 | 2-3/0 | 2-4/0 | 3-3/0 | 4-3/0 | 4-4/0 | | | |
| 1500 | 2-4/0 | 3-3/0 | 3-4/0 | 4-4/0 | | | | |


*Weld cable size (AWG) is based on either a 4 volts or less drop or a current density of not more than 300 circular mils per ampere.

S-0007-C

3-6. Connecting To Weld Output Terminals

NOTE

This unit provides single polarity output to all MOG grids at the same time. Make weld cable connections for the welding polarity required – electrode positive (DCEP) or electrode negative (DCEN).



- 1 Positive (+) Weld Output Terminal
- 2 Negative (-) Weld Output Terminal


For Electrode Positive (DCEP), connect end of one cable to POSITIVE (+) terminal, and remaining end to MOG input terminal.

Connect end of other cable to NEGATIVE (-) output terminal, and remaining end to work circuit.

For Electrode Negative (DCEN), reverse cable connections.


Close door.

Tools Needed:



ST-158 378

3-7. Positioning Jumper Links



Jumper links allow operation on different input voltages and are factory set for the highest input voltage.

Check input voltage available at site.

Open rear access door to check jumper links.



1 Input Voltage Label – Only One Is On Unit

Look at jumper links and compare link position with unit label.


2 Input Voltage Jumper Links

Move links to match input voltage. For example, use 230 volts position when 230 volts input power is available.

Close and secure rear access door or go on to Section 3-8.



Tools Needed:



ssb5.1* 2/92 – Ref. ST-158 381

3-8. Connecting Input Power

Tools Needed:
Screwdriver 1/2, 11/16 in

Have only qualified persons make this installation.

Open rear access door.

- Line Disconnect Switch Of Proper Rating
- Strain Relief Connector

Obtain and install strain relief connector.

- Input Conductors
- Grounding Conductor

Select size and length using Section 3-9 or Section 3-10. Conductor rating must comply with national, state, and local electrical codes. Use lugs of proper amperage capacity and correct hole size.

- Input Terminal Board
- Line Terminals
- Ground Terminal

Insert conductors through strain relief.

Connect input conductors to line terminals and grounding conductor to ground terminal.

Install and connect input conductors and grounding conductor in conduit or equivalent to deenergized line disconnect device.

Be sure grounding conductor goes to an earth ground.

Close rear access door.

- Overcurrent Protection

Select type and size using Section 3-9 or Section 3-10. Install into deenergized line disconnect device (fused disconnect switch shown).

ssb2.4* 2/93 – ST-158 381

3-9. Electrical Service Requirements For 500 Ampere Models*

| Input Voltage | 230 | 460 | 575 |
|--|----------|----------|----------|
| Input Amperes At Rated Output | 106 | 53 | 43 |
| Circuit Breaker Size In Amperes ¹ | 150 | 80 | 60 |
| Fuse Size In Amperes ¹ | 150 | 80 | 60 |
| Input Conductor Size In AWG/Kcmil ² | 2 | 6 | 8 |
| Maximum Input Conductor Length In Feet (Meters) ³ | 155 (47) | 261 (80) | 259 (79) |
| Grounding Conductor Size In AWG/Kcmil ⁴ | 6 | 8 | 10 |

* These values are calculated from the 1996 edition of the National Electrical Code (NEC).

- Standard fuse or circuit breaker size is that closest to 150% of rated input amperage of the welding power source (Article 630-12(a) of NEC).
- Input conductor size is for insulated copper wire with 75°C rating with not more than three single current-carrying conductors in a cable or raceway (Table 310-16 of NEC).
- Maximum length is to prevent more than a 3% voltage drop between service entrance and input terminals of the welding power source (Articles 210-19(a) and 215-2(b) of NEC).
- The grounding conductor shall be colored or identified as specified in the NEC. Grounding conductor size for copper wire is not required to be larger than input conductor (Article 250-95 of NEC).

3-10. Electrical Service Requirements For 750 Ampere Models*

| | | | |
|--|----------|----------|-----------|
| Input Voltage | 230 | 460 | 575 |
| Input Amperes At Rated Output | 164 | 82 | 66 |
| Circuit Breaker Size In Amperes ¹ | 250 | 125 | 100 |
| Fuse Size In Amperes ¹ | 250 | 125 | 100 |
| Input Conductor Size In AWG/Kcmil ² | 2/0 | 4 | 4 |
| Maximum Input Conductor Length In Feet (Meters) ³ | 187 (57) | 270 (82) | 421 (128) |
| Grounding Conductor Size In AWG/Kcmil ⁴ | 4 | 6 | 8 |

* These values are calculated from the 1996 edition of the National Electrical Code (NEC).

1 Standard fuse or circuit breaker size is that closest to 150% of rated input amperage of the welding power source (Article 630-12(a) of NEC).

2 Input conductor size is for insulated copper wire with 75°C rating with not more than three single current-carrying conductors in a cable or raceway (Table 310-16 of NEC).

3 Maximum length is to prevent more than a 3% voltage drop between service entrance and input terminals of the welding power source (Articles 210-19(a) and 215-2(b) of NEC).


4 The grounding conductor shall be colored or identified as specified in the NEC. Grounding conductor size for copper wire is not required to be larger than input conductor (Article 250-95 of NEC).

S-0092-E


SECTION 4 – OPERATION




4-1. Controls




4-2. Safety Equipment




4-3. Work Clamp




4-4. Ammeter And Voltmeter




4-5. Power Control Push Buttons And Pilot Light




4-6. Sequence Of Shielded Metal Arc Welding (SMAW)




4-7. Sequence Of Gas Metal Arc Welding (GMAW)




4-8. Sequence Of Flux Cored Arc Welding (FCAW)



4-9. Sequence Of Gas Tungsten Arc Welding (GTAW)




4-10. Sequence Of Air Carbon Arc Cutting And Gouging (CAC-A)




SECTION 5 – MAINTENANCE & TROUBLESHOOTING

5-1. Routine Maintenance



⚠ Turn OFF all power before maintaining.



3 Months

- Tape Or Replace Cracked Cables
- Replace Unreadable Labels
- Clean And Tighten Weld Terminals

6 Months


- Blow Out Or Vacuum Inside
- During Heavy Service, Clean Monthly
- Fan Motor Sealed Bearings – No Oil Needed

ST-158 379

5-2. Overload Protection



A. Circuit Breaker CB




1 Circuit Breaker

Circuit breaker CB, labeled OVERLOAD, protects the welding power source output circuit from overload. If CB opens, weld output from the welding power source stops. Reduce welding load, and reset breaker.

Ref. ST-059 546-G

B. Fuse F1



500 Ampere Model

Turn OFF welding power source and disconnect input power.



Fuse F1 protects the control circuit from overload. If F1 opens, the unit shuts down.

Remove right side panel.


1 Fuse F1 (see Parts List for size)

Pull fuse from fuse holder. To reinstall, push fuse into fuse holder.


Reinstall side panel.



750 Ampere Model



Tools Needed:



3/8 in

ST-160 758 / ST-158 382-A

C. Overheating

Thermostats TP1 protects the unit from damage due to overheating. If main transformer T1 gets too hot, TP1 opens and weld output stops. Wait several minutes before trying to weld. This unit will not reenergize by means of the POWER CONTROL ON push button until proper cooling has occurred and all thermostats are closed.

5-3. Troubleshooting



| Trouble | Remedy |
|--|---|
| No weld output; unit completely inoperative; pilot light PL1 not on. | Place line disconnect switch in the ON position (see Section 3-8). |
| | Check and replace open line fuse(s) (see Section 3-8). |
| | Check electrical input connections (see Sections 3-7 and 3-8). |
| | Press POWER CONTROL ON button (see Section 4-5). |
| | Thermostats TP1 open; allow a cooling period of approximately fifteen minutes (see Section 5-2C). |
| | Reset circuit breaker CB, if necessary (see Section 5-2A). |
| | Check and replace fuse F1, if necessary (see Section 5-2B). |
| | Check and replace contactor W, if necessary. |
| Weld output available; fan does not run. | Check fan motor and replace, if necessary. |
| | Check for anything blocking fan blades. |
| Limited output and low open-circuit voltage. | Check and replace open line fuse(s) (see Section 3-8). |
| Erratic or improper weld output. | Select correct size weld cables according to Section 3-5. |
| | Clean and tighten weld cable connections (see Section 5-1). |

Notes

SECTION 6 – ELECTRICAL DIAGRAMS




Figure 6-1. Circuit Diagram For 500 Ampere Model






Figure 6-2. Circuit Diagram For 750 Ampere Model

SECTION 7 – PARTS LIST

 Hardware is common and not available unless listed.



ST-160 772

Figure 7-1. Main Assembly (500 Model Illustrated)

Replace Coils At Factory Or Factory Authorized Service Station

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity | |
|----------|------------|----------|-------------|----------|-----|
| | | | | Model | |
| | | | | 500 | 750 |

Figure 7-1. Main Assembly

| | | | | | |
|-------------|-------|-------------|---|----|----|
| .. 1 | | 053 931 .. | COVER, top | 1 | |
| .. 1 | | 120 486 .. | COVER, top | | 1 |
| .. 2 | | 053 930 .. | PANEL, side | 2 | |
| .. 2 | | 059 178 .. | PANEL, side | | 2 |
| .. 3 | | 020 729 .. | WINDTUNNEL, 18 in | 1 | 1 |
| .. 4 | | 032 606 .. | BLADE, fan 18 in 3wg 22deg .500 bore CW | 1 | 1 |
| .. 5 | | 120 422 .. | PANEL, rear | 1 | 1 |
| .. 6 | FM | 032 605 .. | MOTOR, cap perm SP 1/4hp 230VAC 1625rpm | 1 | 1 |
| .. 7 | | 026 627 .. | GASKET, lifting eye cover | 1 | 1 |
| .. 8 | T2 | 036 630 .. | TRANSFORMER, control 100VA 115-230/460V | 1 | 1 |
| .. 8 | T2 | 090 473 .. | TRANSFORMER, kVA 1/2 115-230/460/575V | 1 | 1 |
| .. 9 | W | 114 781 .. | CONTACTOR, def prp 60A 3P 115V (consisting of) | 1 | |
| | | 114 787 .. | COIL, cntor 115V 60A | 1 | |
| | | 114 786 .. | LINK, connecting contactor terminal | 1 | |
| .. 9 | W | 137 901 .. | KIT, contactor | 1 | |
| | WI | 034 895 .. | INTERLOCK, cntor | 1 | |
| .. 10 | F1 | *088 384 .. | FUSE, crtg 1A 600V (230/460) | 1 | 1 |
| .. 10 | F1 | *012 639 .. | FUSE, crtg 6A 600V (230/460/575) | 1 | |
| .. 10 | F1 | *088 384 .. | FUSE, crtg 1A 600V (230/460/575) | 1 | |
| .. 11 | | 070 404 .. | HOLDER, fuse crtg 30A 600V 1P | 1 | 1 |
| .. 12 ... | TE1,2 | 035 398 .. | TERMINAL ASSEMBLY, pri (230/460) (Fig 7-3) | 1 | |
| .. 12 ... | TE1,2 | 038 126 .. | TERMINAL ASSEMBLY, pri (230/460/575) (Fig 7-3) | 1 | |
| .. 12 ... | TE1 | 053 898 .. | TERMINAL ASSEMBLY, pri (230/460) (Fig 7-4) | | 1 |
| .. 12 ... | TE1 | 093 423 .. | TERMINAL ASSEMBLY, pri (230/460/575) (Fig 7-4) | 1 | |
| .. 13 ... | T1 | 093 297 .. | TRANSFORMER, pwr main 230/460 (consisting of) | 1 | |
| .. 14 | | 092 314 .. | COIL, pri/sec | 3 | |
| .. 13 ... | T1 | 093 298 .. | TRANSFORMER, pwr main 230/460/575 (consisting of) | 1 | |
| .. 14 | | 092 315 .. | COIL, pri/sec | 3 | |
| .. 13 ... | T1 | 093 190 .. | TRANSFORMER, pwr main 230/460 (consisting of) | 1 | |
| .. 14 | | 092 311 .. | COIL, pri/sec | 6 | |
| .. 13 ... | T1 | 093 191 .. | TRANSFORMER, pwr main 230/460/575 (consisting of) | 1 | |
| .. 14 | | 092 312 .. | COIL, pri/sec | 6 | |
| | TP1 | 026 181 .. | THERMOSTAT, NC (located in coils) | 3 | 6 |
| .. 15 ... | CT1,2 | 080 075 .. | TRANSFORMER, current 310/5 | 2 | |
| .. 15 ... | CT1,2 | 036 612 .. | TRANSFORMER, current 800/5 | | 2 |
| .. 16 | | 116 977 .. | BASE | 1 | |
| .. 16 | | 117 013 .. | BASE | | 1 |
| .. 17 ... | Shunt | 079 388 .. | SHUNT, meter 50MV 800A | 1 | |
| .. 17 ... | Shunt | 030 635 .. | SHUNT, meter 50MV 1000A | | 1 |
| .. 18 ... | SR1 | 049 778 .. | RECTIFIER, si diode (consisting of) | 1 | |
| .. 18 ... | SR1 | 047 345 .. | RECTIFIER, si diode (consisting of) | | 1 |
| | D1-6 | 037 157 .. | DIODE, rect 275A 250V SP | 12 | 18 |
| | C1-6 | 031 689 .. | CAPACITOR, rectifier | 6 | 6 |
| | R1 | 026 036 .. | RESISTOR, WW fxd 5W 2K ohm | 1 | 1 |
| | VR1 | 035 227 .. | VARISTOR, 8 joule 150V | 6 | 6 |
| .. 19 | | Fig 7-2 .. | PANEL, front w/components | 1 | 1 |


*Recommended Spare Parts.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity | |
|----------|------------|----------|-------------|-----------|-----------|
| | | | | Model 500 | Model 750 |

Figure 7-2. Panel, Front w/Components (Fig 7-1 Item 19)

| | | | | | |
|----|-----|----------|---|---|---|
| 1 | V | 025 638 | METER, volt dc 0-100 scale | 1 | 1 |
| 2 | A | 059 118 | METER, amp dc 50MV 0-800 scale | 1 | |
| 2 | A | 059 120 | METER, amp dc 50MV 0-1K scale | | 1 |
| 3 | | | NAMEPLATE, (order by model and serial number) | 1 | 1 |
| 4 | | 059 570 | PANEL, front | 1 | 1 |
| 5 | CB | 034 945 | CIRCUIT BREAKER, man reset 2P 5A 240VAC | 1 | 1 |
| 6 | PB1 | 011 636 | SWITCH, PB start-stop 10A 550VAC | 1 | 1 |
| 7 | | 053 882 | TERMINAL ASSEMBLY, pwr output (consisting of) | 1 | 1 |
| 8 | | 601 841 | NUT, brs hex jam .625-11 | 4 | 4 |
| 9 | | 602 219 | WASHER, lock stl ext tooth .625 | 2 | 2 |
| 10 | | 602 249 | WASHER, flat stl SAE .625 | 2 | 2 |
| 11 | | 053 866 | TERMINAL BOARD, pwr output | 2 | 2 |
| 12 | | 038 909 | STUD, brs .625-11 x 3.000 | 2 | 2 |
| 13 | | 053 875 | BUS BAR, term pwr output | 2 | 2 |
| 14 | | 601 842 | NUT, brs hex full .625-11 | 2 | 2 |
| 15 | | 053 870 | BRACKET, mtg term board | 1 | 1 |
| 16 | | +120 520 | DOOR, access front lower | 1 | 1 |
| 17 | | 605 583 | CATCH, spr loaded door | 1 | 1 |
| 18 | | 134 327 | LABEL, warning general precautionary | 1 | 1 |
| 19 | | 027 631 | HOUSING, light ind slide base 125V | 1 | 1 |
| 20 | PL1 | *027 629 | BULB, incand slide base 120V | 1 | 1 |
| 21 | | 027 628 | LENS, light ind red clear | 1 | 1 |

 Hardware is common and not available unless listed.




Figure 7-2. Panel, Front w/Components (500 Model Illustrated)

ST-160 771

+When ordering a component originally displaying a precautionary label, the label should also be ordered.

*Recommended Spare Parts.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

| Item No. | Part No. | Description | Quantity |
|---|----------|--|-----------------|
| Figure 7-3. Terminal Assembly, Pri (Fig 7-1 Item 12) | | | 035 398 038 126 |
| 1 | 601 835 | NUT, brs hex 10-32 | 32 ... 46 |
| 2 | 038 058 | TERMINAL BOARD, pri | 1 ... 1 |
| 3 | 038 887 | STUD, pri bd brs No. 10-32 x 1.375 | 16 ... 23 |
| 4 | 010 913 | WASHER, flat brs .218 ID x .460 OD x .031thk | 16 ... 23 |
| 5 | 038 618 | LINK, jumper term bd pri | 8 ... 7 |
| 6 | 601 836 | NUT, brs hex .250-20 jam | 6 ... 6 |
| 7 | 010 915 | WASHER, flat brs .250 ID x .625 OD x .031thk | 6 ... 6 |
| 8 | 038 888 | STUD, pri bd brs .250-20 x 1.500 | 3 ... 3 |




Figure 7-3. Terminal Assembly, Pri (500 Model)




Figure 7-4. Terminal Assembly, Pri (750 Model)

| Item No. | Part No. | Description | Quantity |
|---|----------|--|-----------------|
| Figure 7-4. Terminal Assembly, Pri (Fig 7-1 Item 12) | | | 053 898 093 423 |
| 1 | 601 836 | NUT, brs hex .250-20 jam | 24 ... 36 |
| 2 | 038 652 | LINK, jumper term bd pri | 6 |
| 2 | 038 124 | LINK, jumper term bd pri | 6 |
| 3 | 010 915 | WASHER, flat brs .250 ID x .625 OD x .031thk | 12 ... 18 |
| 4 | 038 889 | STUD, pri bd brs .250-20 x 1.750 | 12 |
| 4 | 038 890 | STUD, pri bd brs .250-20 x 2.125 | 18 |
| 5 | 093 147 | INSULATION, stud barrier | 18 |
| 6 | 602 209 | WASHER, lock stl intl tooth .250 | 12 ... 18 |
| 7 | 026 754 | INSULATION, stud barrier | 12 ... 18 |
| 8 | 010 910 | WASHER, flat stl SAE .375 | 3 ... 3 |
| 9 | 602 213 | WASHER, lock stl SAE .375 | 3 ... 3 |
| 10 | 601 838 | NUT, brs hex .375-16 jam | 9 ... 9 |
| 11 | 601 861 | NUT, stl hex 10-24 | 2 ... 2 |
| 12 | 602 203 | WASHER, lock stl split No. 10 | 2 ... 2 |
| 13 | 010 913 | WASHER, flat brs .218 ID x .460 OD x .031thk | 2 ... 2 |
| 14 | 038 669 | TERMINAL BOARD, pri | 1 ... 1 |
| 15 | 038 621 | BLOCK, term 30A 4P | 1 |
| 15 | 038 622 | BLOCK, term 30A 5P | 1 |
| 16 | 602 112 | SCREW, 10-24 x 1.250rndhd-sltsl stl | 2 ... 2 |
| 17 | 038 620 | LINK, jumper term block 30A | 2 ... 1 |
| 18 | 038 891 | STUD, brs .375-16 x 2.125 | 3 ... 3 |

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

TRUE BLUE® WARRANTY

Effective January 1, 2000
(Equipment with a serial number preface of "LA" or newer)

This limited warranty supersedes all previous Miller warranties and is exclusive with no other guarantees or warranties expressed or implied.

Warranty Questions?

Call
1-800-4-A-MILLER
for your local
Miller distributor.

Your distributor also gives
you ...

Service

You always get the fast,
reliable response you
need. Most replacement
parts can be in your
hands in 24 hours.

Support

Need fast answers to the
tough welding questions?
Contact your distributor.
The expertise of the
distributor and Miller is
there to help you, every
step of the way.

LIMITED WARRANTY – Subject to the terms and conditions below, Miller Electric Mfg. Co., Appleton, Wisconsin, warrants to its original retail purchaser that new Miller equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by Miller. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Miller must be notified in writing within thirty (30) days of such defect or failure, at which time Miller will provide instructions on the warranty claim procedures to be followed.

Miller shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the date that the equipment was delivered to the original retail purchaser, or one year after the equipment is sent to a North American distributor or eighteen months after the equipment is sent to an International distributor.

1. 5 Years Parts – 3 Years Labor
 - * Original main power rectifiers
 - * Inverters (input and output rectifiers only)
2. 3 Years — Parts and Labor
 - * Transformer/Rectifier Power Sources
 - * Plasma Arc Cutting Power Sources
 - * Semi-Automatic and Automatic Wire Feeders
 - * Inverter Power Supplies
 - * Intellitig
 - * Engine Driven Welding Generators
(NOTE: Engines are warranted separately by the engine manufacturer.)
3. 1 Year — Parts and Labor
 - * DS-2 Wire Feeder
 - * Motor Driven Guns (w/exception of Spoolmate 185 & Spoolmate 250)
 - * Process Controllers
 - * Positioners and Controllers
 - * Automatic Motion Devices
 - * RFCS Foot Controls
 - * Induction Heating Power Sources
 - * Water Coolant Systems
 - * HF Units
 - * Grids
 - * Maxstar 140
 - * Spot Welders
 - * Load Banks
 - * Miller Cyclomatic Equipment
 - * Running Gear/Trailers
 - * Plasma Cutting Torches (except APT & SAF Models)
 - * Field Options
(NOTE: Field options are covered under True Blue® for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)
4. 6 Months — Batteries
5. 90 Days — Parts
 - * MIG Guns/TIG Torches
 - * Induction Heating Coils and Blankets

- * APT, ZIPCUT & PLAZCUT Model Plasma Cutting Torches
- * Remote Controls
- * Accessory Kits
- * Replacement Parts (No labor)
- * Spoolmate 185 & Spoolmate 250
- * Canvas Covers

Miller's True Blue® Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, slip rings, relays or parts that fail due to normal wear.**
2. Items furnished by Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than Miller, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MILLER PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at Miller's option: (1) repair; or (2) replacement; or, where authorized in writing by Miller in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Miller's option of repair or replacement will be F.O.B., Factory at Appleton, Wisconsin, or F.O.B. at a Miller authorized service facility as determined by Miller. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.

Some states in the U.S.A. do not allow limitations of how long an implied warranty lasts, or the exclusion of incidental, indirect, special or consequential damages, so the above limitation or exclusion may not apply to you. This warranty provides specific legal rights, and other rights may be available, but may vary from state to state.

In Canada, legislation in some provinces provides for certain additional warranties or remedies other than as stated herein, and to the extent that they may not be waived, the limitations and exclusions set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary from province to province.



Owner's Record

Please complete and retain with your personal records.

Model Name

Serial/Style Number

Purchase Date

(Date which equipment was delivered to original customer.)

Distributor

Address

City

State

Zip



For Service

Call 1-800-4-A-Miller or see our website at www.MillerWelds.com to locate a DISTRIBUTOR or SERVICE AGENCY near you.

Always provide Model Name and Serial/Style Number.

Contact your Distributor for:

Welding Supplies and Consumables

Options and Accessories

Personal Safety Equipment

Service and Repair

Replacement Parts

Training (Schools, Videos, Books)

Technical Manuals (Servicing Information and Parts)

Circuit Diagrams

Welding Process Handbooks

Contact the Delivering Carrier for:

File a claim for loss or damage during shipment.

For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department.

Miller Electric Mfg. Co.

An Illinois Tool Works Company
1635 West Spencer Street
Appleton, WI 54914 USA

International Headquarters—USA

USA Phone: 920-735-4505 Auto-Attended
USA & Canada FAX: 920-735-4134
International FAX: 920-735-4125

European Headquarters – United Kingdom

Phone: 44 (0) 1204-593493
FAX: 44 (0) 1204-598066

www.MillerWelds.com

